

Important information for customers living in flats

Your Sky+HD box may be installed with a single satellite feed

If you have a single satellite feed then please follow the simple steps below to ensure you can continue watching TV and receive complete programme listings. To check if you have a single satellite feed you need to look at the back of your Sky+HD box. You will find two sockets called 'Dish Input 1' and 'Dish Input 2'. If you have a wire going into each, then you have two satellite feeds and this leaflet does NOT apply to you. If you have a single wire going into one of these sockets please read on.

Switching the Single Feed Mode to 'ON'

1. Make sure that the satellite cable is connected to 'Dish Input 1' on the back of your Sky+HD box.
2. Press **Services** on your remote control.



'Options' in the Top Menu will be highlighted in orange.



3. Press the **Right** arrow once to highlight 'Settings' in the Top Menu.



4. Now press the **Down** arrow once to highlight the 'Picture' tab in the Middle Menu.



5. Press **0, 1, Select** on your remote in quick succession. The 'Setup' tab will then be highlighted within the hidden menu.



6. Press the **Down** arrow five times to highlight 'Single Feed Mode' at the bottom of the list.



7. Press the **Right** arrow once to turn 'Single Feed Mode' from 'OFF' to 'ON'. Then press the **Green** button to 'Save Settings'.



8. The message below will be displayed. Your Sky+HD box is now ready to be rebooted - to do this, press **Select**. Please allow a few minutes for your Sky+HD box to reboot.



Once rebooted, your Sky+HD box offers you the same functionality you had before - plus some new exciting features that are highlighted in the brochure. All your recordings will still be there, waiting for you to enjoy.